

D-Link DVA-2800 - VoIP

Complete modem set up guide for your service first before setting up VoIP

Step 1:

Plug modem into computer with the yellow cable supplied. Plug it into the yellow plug on the modem


Step 2:

Open up your internet browser on your computer and use 192.168.1.1 as the URL.




Step 3:

When prompted enter the following Password: admin




Step 4:

Click on "Cancel" when the setup wizard pops up




Step 5:

Hover over "Settings" and then select "Internet"



Step 6:

Change the service type from "Internet" to "Internet_VoIP"



Then click "Save"

Step 7:

Hover over "Settings" and then select "VoIP"



D-Link DVA-2800 - VoIP

Complete modem set up guide for your service first before setting up VoIP

Step 8:

VoIP Provider

Select "LeapTel" as your Provider

Other Configuration

Set the Register Life Time to "3600"

Connection Configuration

VoIP 1: Enabled

Username: Extension Number

Password: Password is found in simj or on the back of your modem. (Older Services have a different password, c Kerio)

URI: Leave blank

VoIP 2: Disabled

Then click on "Save"

Settings >> Basic Advanced **Save**

VoIP Provider

Provider:

Local Port

Port: (1024 ~ 65535)

Main Configuration

Register Server:

Proxy:

Outbound Server:

Port: (1024 ~ 65535) Backup Configuration

Other Configuration

Register Life Time: S

Link Test Interval: S Enable Link Test:

Retry Interval: S Enable P-Asserter-Identity:

Connection Configuration

VoIP1:	VoIP2:
Enable: <input type="text" value="Enabled"/>	Enable: <input type="text" value="Disabled"/>
User Name: <input type="text"/>	User Name: <input type="text"/>
Password: <input type="text" value="*****"/>	Password: <input type="text" value="*****"/>
URI: <input type="text"/>	URI: <input type="text"/>

Step 9:

Follow the instructions that came in the box on a double-sided piece of paper to plug in and connect your modem to the internet and then connect to your modem.