Modem Setup Instructions

NetComm NF10WV

NBN FTTN Connection

Step 1:
Plug modem into computer with the yellow cable supplied. Plug it into the yellow plug on the modem labelled **Eth. 1**

Step 2:
Open up your internet browser on your computer and use 192.168.20.1 as the URL.



Step 3:
When prompted enter the following
User Name: admin
Password: admin



Step 4:
Click on “Management” from the menu on the left.



Step 5:
Click on “Update Firmware” from the menu on the left.



Step 6:
Click on the “Choose File” Button



Step 7:
Select the correct file to upload

Then click on “Open”



Step 8:
Click on “Update Firmware”
This will take a few minutes to load.



Modem Setup Instructions

NetComm NF10WV

NBN FTTN Connection

Step 9:
Once it's loaded the new firmware, the first page should look like this, with the Software Version in the Device Info being the file you just uploaded. (If not, try from Step 4 again).


Device Info

Manufacturer:	NetComm Wireless
Product Class:	NF10WV
Serial Number:	160915533514
Build Timestamp:	161219_0925
Software Version:	NF10WV.NC.AU_R5B023.EN
Bootloader (CFE) Version:	1.0.38-116.174
DSL PHY and Driver Version:	A2pv1041d2.d26b
VDSL PROFILE:	No profile
Wireless Driver Version:	7.14.89.3303.cpe4.16L03.0u-kdb
Voice Service Version:	Voice
Uptime:	0D 0H 34M 30S

Step 10:
Click on "Basic Settings" from the menu on the left.



Step 11:
Select "VDSL" as your WAN connection type
Then click next

Step 12:
Select "Custom VLAN Tag"
Set VLAN Tag to "100"

Then click next



Step 13:
Enter your username and password that was provided to you in an email when your signed up.
Username: your.name@leaptel.com.au
Password: as per email
Then click Finish.



Step 14:
Follow the instructions that came in the box on a double-sided piece of paper to plug in and connect your modem to the internet and then connect to your modem.